## SUCTION CUP MOUNT INSTALLATION INSTRUCTIONS:

Includes: PortaGRIP & 809-AMP Suction Cup Mount Tools Needed: None

- Thoroughly clean the smooth, flat, non-porous mounting surface (windshield, window, mirror, etc.). The surface should be dry and free of any scratches.
- Loosen the Arm Adjusting Knob so the Mounting Arm moves up and down.
- 3. Position the Suction Cup Locking Lever in the "down" position.
- 4. Position the Suction Cup in your mounting area. In order to remove the mount easily, PanaVise recommends that the Suction Cup Release Tab be at the bottom of the installation and that the Mounting Arm moves freely in a vertical line.
- 5. Push the Suction Cup firmly against the mounting surface (the Suction Cup Lever should be in the "down"position).
  Press the Suction Cup Button and pull the Suction Cup Locking Lever up and over the Button. You will feel the Button move out during this procedure; this action locks the Suction Cup into place.

- Move the Mounting Arm up and down to the desired position and lock into place with the Mounting Arm Adjusting Knob.
- Loosen the Adjusting Knob, position the PortaGRIP, then tighten the Adjusting Knob.
- 8. Installation is complete.
- To release the Suction Cup, move the Suction Cup Locking Lever back into its "down"position. Lift the Suction Cup Release Tab to help break the hold.

## HOW TO PLACE YOUR MOBILE DEVICE

- To open PortaGRIP arms, press the release button found on the lower left side of the phone holder.
- To secure your mobile device, place the device in the gripper and squeeze the arms closed. Move the feet and vertical grips to custom fit your device.

