

# THE KANGAROO




Maximum Size LCD Monitor 24" and 15 lbs  
Any questions about The Kangaroo  
Contact us at [info@ergodesktop.com](mailto:info@ergodesktop.com)

The Kangaroo is designed to hold your laptop or LCD monitor on the monitor shelf and your keyboard and mouse on the main work surface.

Your Kangaroo is shipped in the down position with both the monitor shelf brake and the main brakes tightened. The Kangaroo has (2) springs that assist in raising your unit to the standing position and work best when your laptop or monitor and keyboard are in place. This reduces the amount of pressure needed to lower the unit.

**Always push down with both hands on the horizontal rear rail when lowering the main work surface.**



optimal location for support leg

## HOW TO USE THE KANGAROO

To raise the Kangaroo, loosen the main brake(C) and lift the main work surface on the sides(D & D).

To raise the Monitor, loosen the monitor brake(A) and lift the monitor shelf.

To lower the Kangaroo, loosen the main brake(C) and lean into the unit using your upper body weight pushing down with both hands on the horizontal bar at the rear of the main horizontal work surface (B & B).

To Lower the monitor shelf, loosen the monitor brake(A) and push down with one or two hands on the monitor shelf.

**A. Monitor Brake**


**B. Work Surface Rail**

**C. Main Brake**

**D. Main Work Surface**



# THE STABILIZATION LEG



Your adjustable height desk unit comes with an adjustable leg that can be used to give you maximum stability when you are using “The Kangaroo” in the standing position.


Raise The Kangaroo work surface to your desired standing height and tighten the work surface brake.

Place the adjustable leg under the work surface and loosen the adjustable leg brake. Only loosen the brake by a turn or two, to much and the brake will disengage from the slot.

Extend the adjustable leg until it engages the bottom of the work surface and then tighten the adjustable leg brake.

The leg is shipped with the **extension section** installed to give you additional height adjustment. If this is too tall for your application, simply **unscrew the extension section**.

- A** Extension Selection
- B** screws into here



**ALWAYS REMOVE LEG BRACE BEFORE LOWERING THE WORK SURFACE.**

