



Installation Guide AWM-LR

# Dual Crossbar







## IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- Curved monitors, deep devices (such as all-in-one PCs) and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range.
  The manufacturer accepts no responsibility for incorrect installation.
- ! This product is compatible with AWM Series monitor arm products.


## 1. Mount crossbar onto arm




#### 2. Attach handle (Optional)




## 3. Attach VESA plates to monitors




## 4. Mount monitors onto crossbar




## 5. Adjust the ball joint tension




## 6. Install Cables




## 7. Adjust horizontal position of monitors



## 8. Adjust level of crossbar



## 9. Adjust monitor angle



atdec.com | atdec.co.uk | atdec.com.au