



AWM Tilt Bracket





IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- ! Each Bracket supports a maximum weight as per above capacity specification.
- ! This product is not suitable for outdoor use.
- ! Do not use this product for mobile applications.
- ! VESA mounted accessories (such as mini PC brackets and mounts), and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range. Please contact Atdec if you would like further information.

1. Attach VESA Plate to Display

guide for further


information.

1.1 VESA compatibility For 75mm VESA unscrew -1.2 Attach VESA Plate with 1.2 For recessed VESA use 10mm 5mm to access top M4x10 Screws. Spacers and M4x20 Screws. holes. TOP NOTE: Some displays require the use of a VESA adapter before attaching the VESA **75mm** Plate. This VESA adapter may ship =⊚ <u>o</u>= in the box with the F display. Consult your display's installation

2. Slide Bracket onto Post, Set Height and Mount Display

-75mm

100mm



3. Fine Adjustment

